

PANTING ARRANGEMENT

SCALES AS INDICATED



Table with 4 columns: No, Length, Remarks, Remarks. Lists various structural components and their specifications.

Table with 4 columns: No, Length, Remarks, Remarks. Lists various structural components and their specifications.





Table with 4 columns: No, Length, Remarks, Remarks. Lists various structural components and their specifications.







Table with 4 columns: No, Length, Remarks, Remarks. Lists various structural components and their specifications.







Table with 4 columns: No, Length, Remarks, Remarks. Lists various structural components and their specifications.






Table with 4 columns: No, Length, Remarks, Remarks. Lists various structural components and their specifications.

